

Bode Analyzer Suite 3.23

Bugfixes from version 3.22 to 3.23

Bug ID	Description
146986	BAS sometimes freezing when closing
145727	Automation Interface: Results are NaN in ExternalCoupler , ExternalBridge and Impedance Adapter modes
147216	BAS can crash during software-disconnect of Bode device
149415	Plugins not loaded correctly in case of corrupted config file

Known Issues

This is a list of known issues in BAS 3.23 that will be resolved in the next version:

Bug ID	Description	Current workaround
166436	Importing correction values in Automation Interface from BAS .mcalx export can cause wrong measurement results in some cases	Generate .mcalx files in Automation Interface by using SaveCalibration() instead of export in BAS
182009	Shaped level in Automation Interface requires the last frequency/level point defined when using logarithmic sweep	Add the last frequency in the sweep to the shaped-level list.