

# Bode Analyzer Suite 3.25 SR1

## Bugfixes from version 3.25 to 3.25 SR1

Bug ID	Description
225265	Only users with Admin rights can start BAS if they have not started it themselves directly after installation
231768	BAS cannot be installed if a newer version than 5.0.9 of ASP.net is already installed on the system
231747	Some newer Bode 100 Revision 2 devices cannot be programmed.
222332	AI: Source level not read correctly when using GetSourceLevel() with Vrms format.
233298	Old .bode files created in 2013 or before could not be loaded anymore.
227642	Touchstone export not useable when measurement data is missing
235880	LabVIEW is showing Error Message 1172: No free device found

## Known Issues

Known issues in **Bode Analyzer Suite 3.25 SR1** that will be resolved in future:

Bug ID	Description	Current workaround
184547	Recalculate measurement trace values retroactively can lead to deviation at frequencies below 100 Hz	Don't use feature "Recalculate measurement trace values" for measurement data below 100 Hz
195110	PDF report does not work properly on Turkish Windows installations.	Please contact <a href="mailto:support@omicron-lab.com">support@omicron-lab.com</a>

Known issues in **Automation Interface 3.25 SR1** that will be resolved in future:

Bug ID	Description	Current workaround
-	-	-